



Pulsarlube BT App [General Guidance]

Getting Started

Pulsarlube BT App & Server admin access is available after signing up in the App. The admin must create secondary user accounts at <https://bt.pulsarlube.com> in order for accounts to have shared access to the same lubricators.

**Lubricator access cannot be shared between multiple admin accounts created via the App.*


- To sign up, open the App and tap **Sign up**.
- To log in, enter email address and password. Then select either **General [Manage BT]** or **Registration [Register BT]** to start. Lubricators will need to be registered in **Registration** before being able to manage them in **General**.
- **General [Manage BT]** – *to control, check, or modify settings of registered lubricators*
 - Only accounts with General access can control, check, and modify settings of registered lubricators.
 - You are unable to register or unregister lubricators in General.
- **Registration [Register BT]** – *to pair unregistered lubricators to the account*
 - Only accounts with Registration access can pair and unpair lubricators.
 - You are unable to control, check, or modify any lubricator settings in Registration.



Admin accounts will automatically have access to both **General** and **Registration**. When creating secondary accounts, admins can limit secondary account access to either **General** or **Registration**, or grant access to both.

Pulsarlube BT App [General Guidance]

Settings



Back up lubricator data as either a csv or text file when the person in charge of the lubricator changes.

Inquire and check answer

When there has been no update since last synchronization within a preset number of days (ex. 5 days), a push notification pops up.

Pulsarlube BT Lubricator User Manual


Pulsarlube BT App User Manual

Change Language (English, Korean, German, Spanish, Japanese, Chinese, French)

Sign out


Pulsarlube BT App [Registration Access]

Layout & Features



Register Lubricators


- Select lubricators and tap **Register**. If lubricators are not showing up in the App, make sure a battery pack is installed in BT lubricator(s) and tap **Rescan**.



Pulsarlube BT App [Registration Access]


Unregister Lubricators

- Hold lubricator ID for 3 seconds to unregister
- Tap **Confirm** on pop-up menu



Exit from Registration Mode

- Tap **Logout**
- Tap **Logout** on pop-up menu



Pulsarlube BT App [General Access]

Layout & Features

Rescan

Add Group (Add / Move)

Settings

Deselect All

View Lubricator Details

Warning
(Dispensing completion, excessive backpressure, low battery, lubricator update overdue)

Renamed Lubricator

Remaining Grease
Green : 70% ~ 100%
Yellow : 30% ~ 69%
Red : Below 29%

Select / Deselect
Yellow : Selected
White : Deselected

Default Lubricator ID

Renamed

Greyed Lubricator :
Lubricator out of Bluetooth range / Network Error

Lock (Password required to access, in order to prevent accidental changing of settings or tampering)

Group Name



Select / Deselect
Green : Selected
Black : Deselected

Hide or view the lubricators in the group

Pulsarlube BT App [General Access_Naming Lubricators]



Set Lubricator Name

- Select lubricator ID and tap **Rename**



Change Lubricator Name


- Hold lubricator name for 3 seconds and tap **Change name**




Pulsarlube BT App [General Access_Managing Lubricators]

Check Lubricator Status

- Tap the arrow icon to see lubricator status and details




- Tap BT lubricator operation settings to manage settings



Pulsarlube BT App [General Access_Grouping Lubricators]

Create Groups

- Tap **+Add Group**. Create a password to prevent unauthorized access.



Pulsarlube BT

Enter a group name

Enter a new group name


Enter password

Password (4 digits)

Password re-type (4 digits)

Cancel
Confirm


- If the password is not entered for creation of a group, the group lock is unavailable so the lock icon does not appear. The lubricator status and details are also shared among customer employees.



Pulsarlube BT App [General Access_Grouping Lubricators]

Add Lubricators to Existing Groups

- Select lubricators, select group, then tap **+Add Group**.



* **Note** : Only lubricators in range can be added to groups.

(Black : in range / Greyed out : out of range)

Edit Group Settings

- Press and hold group name for 3 seconds. Group settings can be modified only by authorized users after entering password. Admin accounts can change and control group functions without a password.

